

Installation of the Mini UPS for the Thecus N5810PRO

1. Before using the Thecus N5810PRO NAS, please note that the Mini UPS is not installed into the NAS chassis yet. It is placed in an EPE Protector and needs to be installed.
2. After the Mini UPS is installed, please follow the QIG to setup the N5810PRO NAS.
3. If the Mini UPS has been used for a long duration and needs to be replaced, please follow these procedures:
 - 1) Shutdown the NAS by using the power button located on the front panel or through the admin management web interface.
 - 2) Un-plug the AC power cord.
 - 3) Replace the Mini UPS.
 - 4) Plug in the AC power cord.
 - 5) Power on the NAS.